

FIG. 1




FIG. 2




FIG. 3

204040" 2850E00T




FIG. 4

PARAMETER	CONTROL MESSAGE CONTENT
0	START OF CONTROL MESSAGE
1	ADMINISTRATOR IDENTIFIER 502
2	SERVICE TYPE IDENTIFIER 504
3	SERVICE PROVIDER IDENTIFIER 506
4	MACRO CODE (001) 508
5	MACRO CODE (003)
6	MACRO CODE (004)
7	N/A
8	MACRO CODE (002)
9	MACRO CODE (005)
⋮	⋮
X	END OF CONTROL MESSAGE 512

510 {

500

FIG. 5

PARAMETER	ACCESS MESSAGE CONTENT
0	START OF ACCESS MESSAGE
1	ADMINISTRATOR IDENTIFIER 602
2	SERVICE TYPE IDENTIFIER 604
3	USER SUBSCRIBER IDENTIFIER 606
4	MACRO CODE 608
5	610 { MACRO CODE
6	MACRO CODE
7	USER SUBSCRIBER IDENTIFIER 612
8	614 { MACRO CODE
9	MACRO CODE
⋮	⋮
X	END OF ACCESS MESSAGE 616

600

FIG. 6

PARAMETER	OPERATIONAL MESSAGE CONTENT
0	START OF OPERATIONAL MESSAGE
1	ADMINISTRATOR IDENTIFIER 702
2	SERVICE TYPE IDENTIFIER 704
3	SERVICE PROVIDER IDENTIFIER 706
4	710 { MACRO CODE
5	
6	712 { SUBSCRIBER IDENTIFIER
7	
...	...
X	END OF OPERATIONAL MESSAGE 714

FIG. 7




FIG. 8